B TECH

B-TECH AV MOUNTS®

SYSTEM X™

BT8390-WFK1

RAIL MOUNTING BRACKET

INSTALLATION INSTRUCTIONS

ITEM	PART NAME	QTY
1	WALL FIXING PLATE	1
2	M8 SLIDING NUT	2
3	M8 x 12mm CSK SCREW	6
4	ST8 x 45mm CSK WOOD SCREW	2
5	Nº.10 WALL PLUG	2
6	5AF HEX KEY	1

Designed to work in conjunction with B-Tech's System X range

INSTALLATION SAFETY INSTRUCTIONS

⚠ **CAUTION:** This product is intended for use only with the maximum weights indicated. Use with loads heavier than the maximum indicated may result in instability causing possible injury.

B-Tech AV Mounts, it's distributors and dealers are not responsible for damage or injury caused by improper installation, improper use, modifications, installations over the specified weight capacity and/or failure to observe these safety instructions. In such cases, any warranty will expire.

It is recommended that this product should only be installed by a qualified professional / installer.
B-Tech AV Mounts does not claim any liability for any difficulties that may arise from the interpretation contained in these instructions. Failure to mount this product correctly may lead to serious injury and/or death.

Please check carefully to make sure there are no missing or defective parts - defective parts must never be used.
In the event of missing and/or defective parts, or technical questions, please contact an authorised dealer.
Pay careful attention to where this product is located, some locations are not suitable for installation. For indoor use only.
It is recommended that periodic inspections of the product are made as frequently as possible to ensure that safety is maintained.
Please keep these instructions for future reference.

INSTALLATION INSTRUCTIONS

1. ATTACH THE WALL PLATE TO A MOUNTING RAIL

i. Insert *item 2* into the top and bottom channels of a BT8390 mounting rail.

ii. Fix *item 1* to the rail using *items 2 & 3*.

BT8390 RAIL

RAIL

INSTALLATION TOOLS REQUIRED

Drill
10mm (7/16") masonry bit
or 4mm (5/32") wood bit

Pencil   Crosshead screwdriver

Quantity of brackets required per rail length (landscape installs):*

Rail Length	Qty
0 - 2000mm	2pcs
2001 - 3500mm	3pcs
3501 - 5500mm	4pcs
5501 - 7750mm	5pcs
7751 - 8500mm	6pcs

Use B-Tech's online configuration tool to automatically calculate the quantity required based on your configuration.

## 2. FIXING RAIL MOUNTING BRACKET TO THE WALL

Keyhole mounting

i. Mark and drill two fixing holes for each wall plate assembled. Insert *item 5** and *item 4* into the top holes. *Do not fully tighten item 4*, allow a gap (approx. 10mm) to hook on *item 1*.

ii. Hook rail onto *item 4* using the keyhole fixings on *item 1*.

iii. Once the rail is hooked on, screw *item 4* into the bottom holes of *item1* and tighten all fixings.

i.

158mm

WALL

5

4

5

* Item 5 not required for wooden stud walls

ii.

10mm

WALL

4

1

4

iii.

4

### Standard wall mounting

5

4

Pole mounting

Fix *item 1* to a B-Tech collar using *item 3* before attaching the rail and sliding onto a pole.

1

BT7052 COLLAR

3

6

BT7850 POLE

BT7052 COLLAR

BT8390 RAIL

BT8390-WFK1

Note: Ensure the grub screws on the collar are positioned on the back.

BT8390-WFK1

RAIL MOUNTING BRACKET

PRODUCT DIMENSIONS

FRONT VIEW

REAR VIEW

SIDE VIEW

FRONT VIEW: 14mm, 45mm, 6 x Ø8.4mm, 24mm, 186mm, 158mm, 24mm, 81mm

REAR VIEW: 48mm, 2 x Ø8.4mm, 90mm, 93mm

SIDE VIEW: 6mm

These dimensions are intended as a guide only and B-Tech accepts no liability for the accuracy of the information.

CONTACT:
info@btechavmounts.com

AMA-BT8390-WFK1-V2.1-1021-110   MADE IN VIETNAM