

SMA & SMQ Commands manual

Index

Introduction		2
Output list		2
Using the commands		3
SV0x	Set Volume	4
SVU0x	Set Volume Up 3dB	4
SVD0x	Set Volume Down 3dB	4
SR0x	Set Routing	4
SRU0x	Set Routing Up	5
SRD0x	Set Routing Down	5
SM0x	Set Mute	5
GV0x	Get Volume	6
GR0x	Get Routing	6
GM0x	Get Mute	6
GTE	Get Temperature	6

Introduction

Welcome to the command user manual of the AUDAC SMA & SMQ amplifiers. For more info about the SMA and SMQ amplifiers, see the corresponding user manual. This manual only describes the use of the commands for controlling the amplifiers through RS-232.

Input list

0	No input selected	
1	Input 1	
2	Input 2	
3	Input 1+2	
4	Input 3	(Only SMQ)
5	Input 4	(Only SMQ)
6	Input 3+4	(Only SMQ)

Dante inputs (optional)

7	Dante 1	
8	Dante 2	
9	Dante 1+2	
10	Dante 3	(Only SMQ)
11	Dante 4	(Only SMQ)
12	Dante 3+4	(Only SMQ)



Steuerung via ANI44XT:

- Netzwerk
- UDP
- Port 8711

Achtung: Firmware bei SMQxxx 2.0.8 oder höher

Output list

1	Output 1
2	Output 2
3	Output 3 (Only SMQ)
4	Output 4 (Only SMQ)

Using the commands

The SMA and SMQ amplifiers have an RS–232 communication port which can control the standard operation functions of the amplifier as further described in this manual.

It must be configured with 19200 baud, 8 data bits, 1 stop bit, no parity

Command overview

Startsymbol|destination|source|command|argument's|checksum|stopsymbol

Example: Set volume output 1 to –30dB

ASCII: *#IQ001IwebISV01I30IUreturn*

HEX: *237C513030317C5765627C535630317C33307C313262317C0D0A*

Important:

- The address of the SMA or SMQ is fixed at Q001.
- The checksum is CRC–16 excluding the '#'. You can replace the checksum with 'U', this is always accepted as checksum.
- return = 0x0d 0x0a
- source address has a maximum length of 4 characters and cannot contain "I" or "#"

Command flow

- 1) The client sends a command to the SMA or SMQ
- 2) The SMA or SMQ acknowledges the command by returning the same command and a '+' as Argument.
- 3) The SMA or SMQ updates all client's with the new information

All volume and routing settings are saved automatically with every change and will remain when the device is switched off.

SV0x

Set volume of an output to a certain level

Command: SVx, with x the output number whereof the volume should change.
Arguments: Volume in neg dB, 0 is maximum volume, 70 is minimum volume

Example

Set volume of output 2 to -40dB

```
Command #IQ001|web|SV02|40|U|return
Answer #|web|IQ001|SV02|+|U|return
Update #|ALL|IQ001|V02|40|7378|return
```

SVU0x

Set volume with 3dB up for a certain output

Command: SVU0x, with x the output number whereof the volume should increase.
Arguments: 0 (none)

Example

Current is Volume -30dB, set volume up with 3dB for output 1

```
Command #IQ001|web|SVU01|0|U|return
Answer #|web|IQ001|SVU01|+|U|return
Update #|ALL|IQ001|V01|27|U|return
```

SVD0x

Set volume with 3dB down for a certain output

Command: SVD0x, with x the output number whereof the volume should decrease.
Arguments: 0 (none)

Example

Current volume is -27dB, set volume down with 3dB for output 1

```
Command #IQ001|web|SVD01|0|U|return
Answer #|web|IQ001|SVD01|+|U|return
Update #|ALL|IQ001|V01|30|U|return
```

SR0x

Set routing for an output (select input)

Command: SR0x, with x the output where the routing (input) should change for.
Arguments: Input numbers 1 to 6 (3, 4 and 3+4 only for SMQ)

Example

Select input 2 for output 1

```
Command #IQ001|web|SR01|2|U|return
Answer #|web|IQ001|SR01|+|U|return
Update #|ALL|IQ001|R01|2|31|ealreturn
```

SRU0x

Set routing up for an output

Command: SRU0x, with x the output where the routing (input) should increase for
Arguments: 0 (none)

Example

Increase routing for output 1 (current is selected is input 1 which changes to input 2)

```
Command #IQ001|web|SRU01|0|U|return
Answer #|web|IQ001|SRU01|+|U|return
Update #|ALL|IQ001|R01|2|U|return
```

SRD0x

Set routing down for an output

Command: SRD0x, with x the output where the routing (input) should decrease for
Arguments: 0 (none)

Example

Decrease routing for output 1 (current is selected is input 2 which changes to input 1)

```
Command #IQ001|web|SRD01|0|U|return
Answer #|web|IQ001|SRD01|+|U|return
Update #|ALL|IQ001|R01|1|U|return
```

SM0x

Enable / disable mute for a certain output

Command: SM0x, with x the output for which the mute status should change.
Arguments: 0 (disable mute) or 1 (enable mute)

Example

Enable mute for output 1

```
Command #IQ001|web|SM01|1|U|return
Answer #|web|IQ001|SM01|+|U|return
Update #|ALL|IQ001|M01|1|32c6|return
```

GVOx

Get volume info for a certain output

Command: GVOx, with x the number of the output
Arguments: 0 (none)

Example

Get volume info for output 1

Command #|Q001|web|GV01|0|U|return
Answer #|web|Q001|V01|20|U|return

GROx

Get routing info for a certain output

Command: GROx, with x the number of the output
Arguments: 0 (none)

Example

Get routing info for output 1

Command #|Q001|web|GR01|0|U|return
Answer #|web|Q001|R01|3|U|return

GMOx

Get mute info for a certain output

Command: GMOx, with x the number of the output
Arguments: 0 (none)

Example

Get mute info for output 1

Command #|Q001|web|GM01|0|U|return
Answer #|web|Q001|M01|0|U|return

GTE

Get temperature info for all outputs

Command: GTE
Arguments: 0 (none)

Example

Get temperature for all outputs

Command #|Q001|web|GTE|0|U|return
Answer #|web|Q001|TE|36^35^39^42|U|return